

# ATI Thermal Printer Use with iProbe Plus



---

The ATI Thermal Printer can be used as usual with the iProbe Plus connected to the 2i Aerosol Photometer Base Unit. However, please note the following limitations:

- The ATI Thermal Printer will only output the information on the 2i Base Unit. It will not print information entered only on the iProbe Plus (Filter ID, Job ID, Room ID, Tech ID, etc.) or information unique to the iProbe Plus (10-second rewind counts, detailed filter scan data, etc.).
- All iProbe Plus saved information resides only on the iProbe Plus and can be retrieved with a USB-A memory stick. Please refer to the 2i Aerosol Photometer Operator manual (p. 34-38) for information concerning the data output to the ATI Thermal Printer from the 2i Base Unit.
- Control of the ATI Thermal Printer can only be managed through the 2i Base Unit. The iProbe Plus handheld probe cannot control the ATI Thermal Printer. The standard iProbe will continue to allow control of the ATI Thermal Printer through the handle. Please refer to the 2i Aerosol Photometer Operator manual for more information (p. 34-35).